



ART.
SY0038-0003


Spare parts necessarily managed and replaced by authorized Manfrotto centre. Use only silicon grease.




RSY0038-1058
Set of 5





RSY0016-5004 RSY0016-5003




SY0016-0003




SY0005-0002




RSY0031-1016




RSY0038-1047



RSY0030-0007




RSY0038-0006




RSY0038-1057




RSY0032-5004



RSY0032-1017



RSY0038-1031



USB-C Charge Cable



• USB-C to USB-A Cable

Charger



RSY0028-0010



BOX
RSY0038-9011