




Manfrotto
Imagine More

ART.
SY0031-0001




RSY0016-5001




SY0016-0001




RSY0032-5004




RSY0031-1034



RSY0031-1035



RSY0031-1053




SY0005-0002

Spare parts necessarily
managed and replaced by
authorized Manfrotto centre:


- RSY0031 - 1035
- RSY0031 - 1053
- RSY0031 - 1008



RSY0031-1016




RSY0031-1015



RSY0031-1008


NB: carefully
tighten the screws
during the
replacement of
RST0031-1015



RSY0031-0012



- USB-C to USB-A
Female Cable



Charger



RSY0028-0010

BOX
RSY0031-9011